

Instructions for setting up file box:

1. Fold FLAP "A" against inside of carton.
2. Fold FLAP "B" flat against panel bending panel up to form bottom of carton.
3. Turn carton right side up and pick up FLAPS "B" to the sides of the carton.
4. Push down FLAP "A" to the bottom.
5. Fold in FLAPS "C" and "D".

